

Rear Shock Absorbers Addendum

The full 73TEN Kit utilises the CRC Encore shock assemblies in both the centre and side positions. There are a couple of minor changes to the instruction sheet supplied by CRC detailed here.

Side shock assemblies

1. Build as per the CRC instructions but fit the longer ball cup in place of the short one (9). Do not fit the optional O-ring below the piston
2. Fill with 20wt (or 200CST) oil
3. Fit both with the red springs

Centre shock assembly

1. Build as per the CRC instructions but fit the longer ball cup in place of the short one (9). Again, do not fit the optional O-ring under the piston
2. Fill with 40wt (or 500CST) oil
3. Fit with the silver spring