

## Bumper Assembly

To ensure the plastic bumper sits correctly into the carbon mount you will need to remove a small amount of plastic from the underside as shown below.

Trim areas indicated to be flush as in the photo below centre. Attach the plastic bumper to the carbon mount with the three screws and nuts provided.

